




Getting to Know Your 2016



Congratulations on your new Chevrolet Volt.

It's an amazing vehicle, and we're sure you're eager to get behind the wheel and see what it can do. For a quick introduction to the Volt, review this guide. It provides the basic information needed to charge it, start it, and hit the road. Complete details can be found in your Owner Manual.

If you have any questions or would like more information about your Volt, contact a Volt Customer Advisor at 1-877-4-VOLT-INFO (1-877-486-5846).

www.chevrolet.com/volt



Instrument Panel

Power Mirror Controls/Power Window Controls/Rear Windows Lock

Instrument Panel Illumination Control

Turn Signal Lever/Exterior Lamps Control

Regen on Demand Paddle (behind steering wheel)

Instrument Cluster/Driver Information Center

Windshield Wipers Lever



Fuel Door Release

Cruise Control/Forward Collision Alert/Lane Keep Assist/Heated Steering Wheel Controls

Audio Favorite Stations Buttons

Tilt/Telescopic Steering Wheel Lever (on steering column)


Audio Volume Buttons (behind steering wheel)


Voice Recognition Controls/5-Way Control

Power Button

Symbols

 BRAKE Brake System

 Safety Belt Reminder

 Airbag Readiness

 High Beam Headlamps

 Engine Oil Pressure

 12V Charging System

 Forward Collision Alert

 Lane Keep Assist Warning


 Engine Coolant Temperature

 Security

 Service Electric Parking Brake

 Electric Parking Brake Set

 Cruise Control

 Door, Hood or Hatch Open

Charging Status Indicator

MyLink Infotainment System

Climate Controls/Driver's and Passenger's Heated Seat Controls



Electric Parking Brake

Hazard Warning Flashers

Drive Mode Selector

Traction Control/ Park Assist/ Auto Park Assist Buttons

Accessory Power Outlet, USB Ports/Auxiliary Input Jack



Low Fuel



Antilock Brake System



Lights On Reminder



Low Tire Pressure



StabiliTrak/Traction Control



Traction Control Off



StabiliTrak Off



Check Engine



Vehicle Ready

Refer to your Owner Manual to learn about the information being relayed by the lights, gauges and indicators of the instrument cluster.

See In Brief in your Owner Manual.

Getting Started

Remote Keyless Entry (RKE)

The RKE transmitter performs several remote functions and must be inside the vehicle to operate the Volt.

Keyless Access

With the RKE transmitter within 3 ft. (1 m) of the door, press the button on the door handle to unlock the door. Press it again within 5 seconds to unlock all doors.

Key Release

Press the side button to remove the key, which can be used to unlock the driver's door.

Unlock

Press to unlock the driver's door. Press again to unlock all doors.

Press and hold to lower all windows from outside the vehicle.



To turn the window feature on/off, select Settings > Vehicle > Remote Lock, Unlock, Start > Remote Window Operation.


Lock

Press to lock all doors




Remote Start

Press the  **Lock** button and then press and hold the  button until the turn signal lamps flash to start the vehicle and condition the passenger cabin temperature from outside. The heating or air conditioning system and rear window defogger (if needed) will turn on. Depending on conditions and vehicle personalization settings, the engine may start.

After entering the vehicle, press the brake pedal and then press the  **POWER** button before driving.

Note:

- Press and hold the  **Remote Start** button until the parking lamps turn off to cancel a remote start.
- Only two remote starts are allowed between ignition cycles.
- It's RECOMMENDED to use this feature when the vehicle is plugged in to allow energy from the wall outlet to assist in getting the cabin to a comfortable temperature and to leave more battery energy for driving.

Panic Alarm

Press and release to locate the vehicle.

Press and hold for 3 seconds to sound the panic alarm.

See Keys, Doors and Windows in your Owner Manual.


Getting Started

POWER Button

The Volt features an electronic push-button start. The  **POWER** button flashes when the driver's door is opened upon entry. Once the vehicle is ON, the button illuminates.

Note: The air conditioning compressor, pumps and fan may run at any time, even when the vehicle is OFF, to cool or warm the propulsion battery.

Starting the Vehicle/ON

- ▶ With the vehicle in Park or Neutral, press the brake pedal and then press the  **POWER** button. A power ON audio cue will sound.

The vehicle will not shift out of Park and a Charge Cord Connected message will display if the vehicle is still plugged in.

When ON, the instrument cluster will display an active battery or fuel gauge. The engine will start only if needed.



Stopping the Vehicle/OFF

- ▶ Shift to Park and then press the  **POWER** button. A power OFF audio cue will sound.

Conditions for Engine Starting

When vehicle power is ON, the engine may start independent of the vehicle being plugged in or completely charged. Conditions that may cause the engine to start include:


- Propulsion battery charge is low
- Propulsion battery temperature is hot or cold
- Cold ambient temperatures (depending on engine-assisted heating options, see Vehicle Personalization on page 10)
- Hood is open
- Engine and Fuel Maintenance Modes (occur only if the engine has had very limited operation over a long period)

See Driving and Operating in your Owner Manual.

Steering Wheel and Seat Adjustment

Before driving, adjust the steering wheel and seat to a comfortable position.

- ▶ Pull down the lever (A) to unlock the steering wheel and adjust its position.
- ▶ Lift the handle (B) under the right-front side of the seat to slide the seat forward or rearward.
- ▶ Ratchet the side lever (C) up or down to raise or lower the seat.
- ▶ Lift the rear lever (D) to adjust the seatback.



See Seats and Restraints in your Owner Manual.

Electric and Extended-Range Modes

The Volt is an electric vehicle with extended range capability. Plug it in, let it charge and it's ready to run on pure electricity — gas- and tailpipe emissions-free. After that, the Volt keeps going, even if you can't plug it in. The Volt uses a range-extending gas engine that produces enough energy to power it for hundreds of miles on a single tank of gas.

Electric Mode

In Electric Mode, the vehicle will not use gasoline or produce tailpipe emissions unless in extreme temperatures. During this primary mode, the vehicle is powered by electrical energy stored in its propulsion battery. It can operate in this mode until the battery is depleted to a predetermined level. The propulsion battery gauge and electric range estimate are highlighted when the vehicle is operating in Electric Mode. The fuel gauge and fuel range are dimmed.



Electric range is affected by colder outside temperatures. During colder months, the energy needed to warm the vehicle's cabin and propulsion battery can cause the vehicle's electric range to decline. See Driving for Better Energy Efficiency in the Driving and Operating section in your Owner Manual.

Extended-Range Mode

Once the electric charge is depleted, the range-extending gas engine will start to provide power to continue driving the vehicle. The engine ensures that you will not be stranded by a depleted battery. The vehicle determines when the engine needs to run. Engine speed will vary, depending on driving conditions, to optimize efficiency. The engine will not fully charge the propulsion battery. The vehicle must be plugged in to recharge. The fuel gauge and fuel range estimate are highlighted when the vehicle is operating in Extended-Range Mode. The propulsion battery gauge is dimmed.



Total Vehicle Range

Total vehicle range is based on the available combined electric and extended range. The displayed electric and fuel ranges are projections based on past vehicle performance and charge/fuel level. The displayed ranges will change based on driving style, outside temperature and climate settings.

The Total Range indicator can be selected in the instrument cluster Information menu.



See Driving and Operating in your Owner Manual.

Instrument Cluster

The instrument cluster features an LCD screen that can be configured in four different layouts.

Classic – Displays basic information on speed, range and other operations.

Classic Enhanced – Displays basic information plus driving efficiency and power usage information.

Modern – Displays basic information on speed, range and other operations along with an efficiency ring that glows green to yellow based on driving efficiency.

Modern Enhanced – Displays basic information and the efficiency ring plus additional power usage information.

Cluster Display Zones

- ▶ Press the left or right side of the 5-way control on the right side of the steering wheel to move between the different display zones.
- ▶ Press the 5-way control up or down to scroll through the display menus.
- ▶ Press ✓ to select a highlighted item.

Cluster Configurations

1. Use the 5-way control to select the Configurations page in the left display zone on the cluster.
2. Scroll to highlight Display Layout; press ✓.
3. Scroll to highlight one of the cluster display layouts; press ✓.
4. Press ◀ to exit the menu.

Cluster Tutorial


To view tutorials about the features of the instrument cluster, with the vehicle in Park, use the 5-way control to select Tutorials from the Settings menu.



Classic layout



Modern Enhanced layout



See Instruments and Controls in your Owner Manual.

Efficiency

Driving Style

Your driving style plays a large role in the efficiency of the vehicle. Avoid rapid acceleration or deceleration to help maximize energy efficiency and range. Electric range is maximized at 50 mph and below; higher speeds use more energy and significantly reduce electric range.

Efficiency Gauge

- ▶ Use the 5-way control to select an instrument cluster theme that displays the green ring or leaf indicator.

While driving, try to keep the ring green or the leaf in the center of the gauge. The ring will turn yellow or the leaf will move up or down during inefficient acceleration or aggressive braking, depending on the cluster theme.



Driver-Selected Operating Modes

- ▶ Press the **MODE** button on the center console to scroll through a menu of operating modes for when more performance is needed. After 3 seconds, the highlighted mode will become active.

Normal (Default)

Use in normal driving conditions for efficient operation; is active each time the vehicle is started.

Sport

Use for a sportier driving experience; increases throttle response.

Mountain

Use when planning to drive in mountainous terrain (long grades of 5% or higher); reserves battery power to maintain higher speeds on steep grades.

Hold

Use to preserve electric range for later use. Range-extending operation will engage.

Regen on Demand™

Regen on Demand temporarily regenerates energy from the vehicle's momentum and stores it in the high voltage propulsion battery for later use.

- ▶ To activate Regen on Demand, pull and hold the left paddle on the back of the steering wheel without pressing the brake pedal or accelerator pedal.

While pulling the paddle, the vehicle will begin to decelerate using regenerative braking. Regen on Demand is deactivated once the paddle is released, or the brake pedal or accelerator pedal is pressed.



See Driving and Operating in your Owner Manual.

Efficiency

Climate Settings

Optimal efficiency is achieved with the climate system off (climate power button indicator is not illuminated). If using the climate mode settings, the most efficient operation is in the following order:

Fan Only – electric cabin heating/cooling is off (eco and MAX button indicators are not illuminated)


eco – limits cabin heating/cooling to balance comfort with energy use (eco button indicator is green)

MAX – provides the most cabin heating/cooling, but uses the most energy (MAX button indicator is amber)

Use the heated seats and heated steering wheel (if equipped) to reduce the demand on the cabin heating system. Heating the seats and steering wheel uses less energy than heating the vehicle interior.

See Climate Controls in your Owner Manual.

Information Displays

- ▶ Press the  **Energy** button on the touch screen and then touch the Flow, Charging, or Info icon at the bottom of the screen to display the desired energy information.

Flow

The Power Flow screen indicates the current system operating condition, showing the power flow between the high voltage propulsion battery, electric drive unit and engine. Each component is highlighted when it is active.

Note: Component location in graphic is not representative of actual on-vehicle location.

Charging

The Charging screens show the Charge Limit and Charge Mode status. The vehicle has three programmable charge modes:

- Immediately upon plug-in
- Delayed based on departure time
- Delayed based on electric rates and departure time

Charge Complete times are estimates and most accurate at moderate temperatures. The Charge Limit and Charge Mode can be changed by touching the text. (See Charging on page 12.)

Info

The Info screens show the Energy Usage (Electric Mode and Extended-Range Mode) since the last time the vehicle was fully recharged and the Lifetime Fuel Economy of the vehicle.



See Instruments and Controls in your Owner Manual.

Settings, Sights and Sounds

Refer to your Owner Manual for important safety information about using the infotainment system while driving.

Vehicle Personalization

Some vehicle features can be customized using the menus on the touch screen. The Vehicle Settings menu may include Climate and Air Quality; Collision/Detection Systems; Comfort and Convenience; Energy; Lighting; Power Door Locks; or Remote Lock, Unlock, Start.

1. Touch Settings on the Home page.
2. Touch Vehicle from the Settings menu.
3. Touch the desired menu item.
4. Touch the desired feature and setting.
5. Touch < Back to exit each menu.




MyLink Infotainment

The Infotainment system features radio, auxiliary device input, voice recognition and Bluetooth® phone and audio functions, and available navigation.

- ▶ Connect an auxiliary device to the input jack or USB port, located in the compartment forward of the shift lever.
- ▶ To pair a Bluetooth phone using voice recognition, press the **Push to Talk** button on the steering wheel; after the beep, say “Pair Phone,” or use the touch screen to select Settings > Bluetooth > Pair Device. Follow the pairing instructions.

For more information, visit my.chevrolet.com/learn.

Apple CarPlay™

Apple CarPlay capability may be available through a compatible smartphone. If available, a  Projection icon will appear on the home page of the infotainment display.

1. Connect your Apple iPhone by plugging the compatible phone USB cable into a USB data port. Use your device's factory-provided USB cable. Aftermarket cables may not work.
2. The  Projection icon will change to Apple CarPlay, depending on the phone. Apple CarPlay may launch automatically upon USB connection. If not, touch the Apple CarPlay icon on the home page.

For more information on using Apple CarPlay, visit my.chevrolet.com/learn or call 1-855-4-SUPPORT (1-855-478-7767).

OnStar with 4G LTE

With OnStar 4G LTE and Wi-Fi®, up to seven devices (smartphones, tablets and laptops) can be connected to high-speed Internet through the vehicle's built-in Wi-Fi hotspot.

- ▶ To retrieve the SSID and password for the hotspot, press the white OnStar Voice Command button on the overhead console, wait for the prompt, and then say “Wi-Fi settings.” The information will be displayed on the screen.

For assistance, press the blue OnStar button or call 1-888-4-ONSTAR (1-888-466-7827).

Settings, Sights and Sounds

Siri® Eyes Free

Siri Eyes Free allows hands-free access to the voice recognition commands on a compatible iPhone®. The cell phone must be paired to the in-vehicle Bluetooth system. For more information, visit my.chevrolet.com/learn.

- ▶ To activate Siri Eyes Free, press and hold the  **Push to Talk** button on the steering wheel until tones sound.

Wireless Charging for Mobile Devices♦

The Wireless Charging system is located under the center console armrest. A compatible wireless charging adapter (not supplied) for the device may be needed. For more information and to check mobile device compatibility, visit my.chevrolet.com/learn.

1. The vehicle must be on.
2. Remove all objects from the charging slot.
3. Place the mobile device upright, facing the rear seats, in the charging slot.
4. Move the device slowly until the battery charging symbol displays on the center touch screen, indicating the device is charging.



See Infotainment and Instruments and Controls in your Owner Manual.

Climate Controls



Note: Under certain conditions, the engine will start to ensure full heat and defrost capability.

The indicators on the climate controls show which feature is active:  Climate Power,  Auto Airflow,  Auto Fan, eco, MAX, or  Defrost.

Climate temperature is displayed on the temperature knob. Changes in the climate system functions are displayed on the touch screen.

- ▶ Press the **AUTO** button to have the system operate automatically.

See Climate Controls in your Owner Manual.

Charging

Battery


The Volt is powered by a lithium-ion high voltage battery pack, which holds its charge efficiently and has no memory effect (so it doesn't have to be run down completely before recharging). Keep the vehicle plugged in, even when fully charged, to keep the battery temperature ready for the next drive.

Charging Time

Using a 120-volt standard outlet will take approximately 13 hours to charge the Volt at the 12 amp settings, or 19 hours at the 8 amp default setting. Using a 240-volt charging station will take approximately 4.5 hours to charge. Charge times will vary with outside temperature.

Programmable Charging

The Volt can be programmed for three charging modes: Immediately upon plug-in; Delayed based on departure time; and Delayed (Electric Rate and Departure Time).

- ▶ Touch the  **Energy** icon on the touch screen and then touch the Charging icon to view the current Charge Mode and Charge Limit.
- ▶ Touch the Charge Limit text to select a different charge limit.
- ▶ Touch the Charge Mode text to select a different charge mode.

Charging Status

The Charging Status indicators are located on the instrument panel near the windshield and on the illuminated charge port (if available).

Charging Status Indicator

Single tone and flashing indicator – Vehicle is plugged in; battery is charging. Flashes indicate current percentage of battery charge.

1 flash: 0–25% charged

2 flashes: 25–50% charged

3 flashes: 50–75% charged

4 flashes: 75–99% charged

Solid light: 100% charged



Slow (long pulse) flashing green indicator with double tone – Vehicle is plugged in; battery charging is delayed

Solid green indicator – Vehicle is plugged in; battery is fully charged

Solid yellow indicator – Vehicle is plugged in; not charging

No light – Vehicle is not plugged in OR there is an issue with the charger or outlet

No light and repetitive tones – Issue with the charge cord connection

See Driving and Operating in your Owner Manual.

Charging

Start Charging

The provided 120-volt portable charge cord is located in the driver-side storage compartment in the cargo area.

1. With the vehicle parked, turn off the vehicle and select the Charging screen button at the bottom of the Energy Summary screen.
2. Review the selected Charge Mode and Charge Limit. Select the Limit screen button if an increased charging limit is desired. Use the reduced charge limit until a qualified electrician inspects your home's electrical circuit capacity, or if the electrical circuit or outlet capacity is not known.


Note: The charge limit selection returns to the reduced limit each time the vehicle is driven.

3. Plug the charge cord into an electrical outlet. DO NOT PLUG INTO AN EXTENSION CORD. Charge cord indicators should be green. Where possible, secure the charge cord to the wall.
4. Press and release the rear edge of the charge port door, located just in front of the driver's door, to open it. Plug the charge cord into the charge port.
5. The Charge Status indicator on top of the instrument panel will illuminate green and a tone will sound when properly connected.
6. Periodically check the electrical outlet/plug while charging. Discontinue use if the electrical outlet/plug is hot and have the electrical outlet serviced by a qualified electrician.

If the vehicle is locked with the RKE transmitter, the charge cord theft alert is armed automatically after 30 seconds.

Note: When the theft alert is armed, the alarm will sound when the plug is disconnected from the vehicle. To change charge cord theft alert options, go to Energy in the Vehicle Settings menu.

- To temporarily override a delayed charge event, remove and reconnect the charge cord to the vehicle within 5 seconds. It will begin charging immediately.



See Driving and Operating in your Owner Manual.

Charging

End Charging

1. Unlock the vehicle with the RKE transmitter to disarm the charge cord theft alert.
2. Unplug the charge cord from the vehicle by squeezing the top latch button.
3. Unplug the charge cord from the electrical outlet.
4. Stow the charge cord.



Location-Based Charging

Charging settings can be saved for your home location and the vehicle will automatically revert to these settings when parking at its “home” location.

1. In the Vehicle Settings menu, select Settings > Vehicle > Energy > Location-Based Charging.
2. Select On.
3. Select Update Home Location. Add the required information to set the current vehicle location as the home location.



When away from the home location, the Volt will charge immediately when plugged in.

Home Charging Station

Charging equipment with a rating of at least 240Volt/20Amp will provide the fastest charging time to recharge the propulsion battery.


For more information about an available 240V home charging station, contact your dealer or a Volt Customer Advisor, go to www.pluginnow.com/go/volt, or call 1-877-805-3873.



See Driving and Operating in your Owner Manual.

Fueling

Filling the Fuel Tank



1. Turn off the vehicle and press the  **Fuel door release** button, located on the driver's door, for 1 second. The Wait to Refuel message will display on the instrument cluster.
2. When the Ready to Refuel message displays, the fuel door on the passenger's side of the vehicle will unlock. It will not open automatically.
3. Press the rear edge of the fuel door; it will pop open slightly. Open the door to refuel the vehicle.



See Driving and Operating in your Owner Manual.

Parking

Electric Parking Brake

- ▶ To apply the parking brake, pull the  Parking Brake switch by the shift lever.
- ▶ To release the parking brake, with the vehicle powered ON, press the brake pedal and press the  Parking Brake switch.

See Driving and Operating in your Owner Manual.

Low Ground Clearance

The low ground clearance of the Volt aids in the aerodynamic efficiency of the vehicle. As a result, the flexible air deflector under the front fascia (bumper) may contact a parking block or curb if the vehicle is parked too closely. Use care when parking to avoid damage.



See Vehicle Care in your Owner Manual.

Pedestrian Safety Signal

The vehicle is equipped with an automatic sound generator. The sound is automatically generated at speeds below 20 mph to indicate the vehicle's presence to pedestrians.

See Driving and Operating in your Owner Manual.

Roadside Assistance

1-888-811-1926

TTY Users: 1-888-889-2438

As the owner of a new Chevrolet, you are automatically enrolled in the Chevrolet Roadside Assistance program for 5 years/60,000 miles, whichever occurs first, at no expense to you. Chevrolet's Roadside Assistance toll-free number is staffed by a team of trained advisors who are available 24 hours a day, 365 days a year, to contact a service provider for light services (fuel delivery, jump-starts, flat tire and lock-outs) or make arrangements to tow your vehicle to the nearest Volt Authorized Chevrolet dealer.

Roadside Assistance and OnStar®

If you require roadside service and have a current OnStar subscription, press the OnStar button and the vehicle will send your current GPS location to an OnStar Advisor who will speak to you, assess your problem, contact Roadside Assistance and relay your exact location so you will get the help you need.

myChevrolet & OnStar RemoteLink® Key Fob Services

The myChevrolet mobile app connects owners to a variety of vehicle information and services, such as a searchable Owner Manual and Roadside Assistance.

OnStar RemoteLink Key Fob Services enable users to perform Remote Keyless Entry transmitter commands as well as checking current battery charge level and initiating charging of your Volt. To learn more about OnStar services, press the OnStar button, refer to your Owner Manual, call 1-888-466-7827 or visit **onstar.com**.

Download the mobile apps from your compatible mobile device's app store.

MyVolt.com Owner Site

MyVolt.com is a complimentary resource for Volt owners powered by OnStar. Owners can communicate with their vehicle online to check pertinent vehicle information and perform a number of remote commands. Also available are online service reminders, vehicle maintenance tips, an online owner manual and more.

To create your OnStar username and password:

1. Visit **myvolt.com**.
2. Click the "Sign Up" link.
3. Enter your OnStar account number and ZIP code (available from your OnStar confirmation email, your dealership, or by calling 1-888-4-ONSTAR).
4. When prompted, select "Enable Remote Commands" to ensure all features within the OnStar RemoteLink mobile app are available.

We recommend always using ACDelco or genuine GM service parts.

Certain restrictions, precautions and safety procedures apply to your vehicle. Please read your Owner Manual for complete instructions. All information contained herein is based on the latest information available at the time of printing and is subject to change without notice. Copyright 2015 General Motors. All rights reserved.



23137941 A